

1. Remove wheel sets (1) from chassis.
2. Fit the brake frame accessory (2) into the brake shoe moulding (3), as shown below.
3. Replace wheel sets into chassis.

