## 5. Spare Parts

Selected spare parts are available from the Bachmann Europe Service Department. For further information and enquiries please contact the Service Department directly by email on **service@bachmann-europe.co.uk** or by phone **01455 841756.** 

## 6. Product Warranty

This product has a Warranty for 12 months from the date of purchase against faulty materials or workmanship subject to the following conditions. During this period such defects that occur will be repaired or defective parts replaced free of charge.

- 1. This Warranty applies only if the item was purchased from an authorised retailer of Bachmann Europe plc ('Bachmann') within the European Union / EEA. This Warranty does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. The Warranty is offered as an additional benefit and does not affect your statutory rights as a consumer.
- 2. For claims under this Warranty, the product must be returned to Bachmann at the owners expense and risk directly to Bachmann Europe plc, Moat Way, Barwell, Leicestershire LE9 8EY with evidence of the purchase date in the form of retailer receipt/invoice accompanied by a letter or Service Request form setting out the date and place of purchase, giving a brief explanation of the problem that has led to the claim. It is essential that the claim reach the above address on or before the last day of this Warranty period. Late claims will not be considered.
- 3. This Warranty is only available to the original retail purchaser of this product and is non-transferable.
- **4.** The Warranty does not extend to cover damage resulting from misuse or careless handling, accidental damage, wear and tear, or use on a voltage supply other than that stamped on the product.
- **5.** The Warranty may be considered void if repairs have been attempted other than by Bachmann staff.
- **6.** The Warranty is on the original product in its entirety and does not extend to individual components removed from the product. In respect of train sets the warranty applies to motorized units and controllers only.
- 7. If Bachmann chooses to replace a product it will be with the nearest appropriate model of its choice.
- **8.** Bachmann reserves the right to decline service to any model that has been fitted with a decoder after manufacture.
- **9.** Bachmann will not be held responsible for damage to or loss of an after market decoder fitted to a model submitted for service under the Warranty.
- **10.** The fitting of a Bachmann decoder with a current Warranty shall not be deemed to change the position regarding a product that is otherwise outside its own Warranty. It may be necessary to change decoder settings during service.
- 11. Bachmann's liability under this Warranty will in no case exceed the price paid for the product as originally manufactured.

DACILMANA EUROPE PIC

Bachmann Europe Plc Moat Way, Barwell, Leicestershire, LE9 8EY, England. www.bachmann.co.uk



## Welcome

Many thanks for purchasing one of our **Graham Farish** Class 40 Locomotives. A lot of care was taken producing your model and we hope you enjoy it for many years to come.


**Please note:** This model has been designed to run on curves of **no less than 2nd Radius** (263.5mm). We recommend that you don't use anything smaller as this may result in the model derailing.

For best results don't use with Electronic Track Cleaners.


## 1. Accessories

Although our models are highly detailed and ready to run straight from the box we also supply optional accessories to be fitted by the owner if they wish. Some of the accessories should only be fitted for static display as they may affect coupling or running quality, these parts will be labelled as such below.


**Please note:** PVA based adhesive should be used for the fitting of accessories.




- 1 Vacuum Pipe remove standard coupling.
- 2 Dummy Hook
- 3 **Steam Pipe** remove standard coupling.



- 4a Multiple Working Bogie Cable (Left)
- 4b Multiple Working Bogie Cable (Right)
- 5 Multiple Working Socket
- 6 Multiple Working Cable







- 8 Full Disc
- 9 Upper Half Disc 10 Lower Half Disc
- 11 Next18 DCC Blanking Plate
   Sound fitted locomotives have a DCC
  Blanking Plate included for those who wish
  to remove the DCC Sound Decoder.

F7118 Instruction Sheet - 1704 4 F7118 Instruction Sheet