

## Daisy the Diesel Railcar™

### **Owner's Information**

#### Welcome

Thank you for purchasing this Bachmann **Daisy the Diesel Railcar<sup>TM</sup>** model locomotive. This detailed working replica will give you years of pleasure and reliable operation if it is handled with care and regularly serviced.

#### **Running in**

It is necessary that this Locomotive is 'run-in' to allow the mechanism and gears to settle. This requires the model to be run without a load (wagons, coaches, etc.) for 30 minutes in each direction at half speed.

#### Lubrication

All Bachmann model locomotives are supplied ready lubricated and can be used straight from the box. Over time your locomotive will require some additional lubrication, when will depend on the frequency of use and storage, so please inspect your model on a regular basis.

**Please note:** A plastic compatible lubricant is required. Suitable products from both the Bachmann Trains & Woodland Scenics ranges are available from your local Bachmann retailer.


#### **Next18 DCC Decoder Fitting**

Your Bachmann **Daisy the Diesel Railcar**<sup>TM</sup> model locomotive comes ready to be adapted for Digital Command Control (DCC). The conversion of this locomotive to DCC operation is a simple task.

# To fit a Next18 DCC decoder please follow these instructions.

A Next18 DCC Decoder Socket has been cleverly hidden under Daisy's body.

- 1. Ease the face from the body, taking care not to damage the moving eye mechanism.
- 2. Remove the eight chassis screws and gently pull the body away from the chassis.
- **3**. Remove the DCC Blanking Plate.
- 4. Replace with a Bachmann E-Z Command Next18 DCC decoder, item number **36-567A**.



#### **Spare Parts**

Selected spare parts are available from the Bachmann Europe Service Department. For further information and enquiries please contact the Bachmann Europe Service Department directly by email on **service@bachmann-europe.co.uk** or by phone **01455 245575.** 

#### Warranty

This product has a Warranty for 12 months from the date of purchase against faulty materials or workmanship subject to the following conditions. During this period such defects that occur will be repaired or defective parts replaced free of charge.

- 1. This Warranty applies only if the item was purchased from an authorised retailer of Bachmann Europe PLC ('Bachmann') within the United Kingdom, European Union & European Economic Area. This Warranty does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. The Warranty is offered as an additional benefit and does not affect your statutory rights as a consumer.
- 2. For claims under this Warranty, in the first instance the product must be returned to the retailer with evidence of the purchase date in the form of retailer receipt/invoice accompanied by a letter or Service Request form setting out the date and place of purchase, giving a brief explanation of the problem that has led to the claim. It is essential that the claim reach the retailer on or before the last day of this Warranty period. Late claims will not be considered.
- 3. This Warranty is only available to the original retail purchaser of this product and is non-transferable.
- 4. The Warranty does not extend to cover damage resulting from misuse or careless handling, accidental damage, wear and tear, or use on a voltage supply other than that stamped on the product.
- 5. The Warranty may be considered void if repairs have been attempted other than by Bachmann staff.
- **6.** The Warranty is on the original product in its entirety and does not extend to individual components removed from the product. In respect of train sets the warranty applies to motorized units and controllers only.
- 7. If Bachmann chooses to replace a product it will be with the nearest appropriate model of its choice.
- 8. Bachmann reserves the right to decline service to any model that has been fitted with a decoder after manufacture.
- 9. Bachmann will not be held responsible for damage to or loss of an after market decoder fitted to a model submitted for service under the Warranty.
- 10. The fitting of a Bachmann decoder with a current Warranty shall not be deemed to change the position regarding a product that is otherwise outside its own Warranty. It may be necessary to change decoder settings during service.
- 11. Bachmann's liability under this Warranty will in no case exceed the price paid for the product as originally manufactured.



www.bachmann.co.uk









## Join us at the Bachmann Collectors Club

The Bachmann Collectors Club is the official club for Bachmann enthusiasts. Our aim is to keep members up to date with the latest news and views from Bachmann and give them the chance to purchase and collect exclusive limited edition Bachmann Branchline and Graham Farish products.

#### Standard Membership

- The opportunity to purchase Limited Edition Models, produced for the Collectors Club with up to 10% off the standard RRP
- Four copies of the quarterly 'Bachmann Times' magazine
- Four copies of the quarterly 'British Railway Announcements' catalogue
- A copy of the annual 'Combined Volume' model railway catalogue
- A limited edition collectable OO, N or OO9 scale Club wagon (depending on chosen membership option)
- A Pin badge and personalised membership card
- Calendar featuring photos from the members photographic competition
- · Monthly news via our 'Train Mail' e-newsletter
- Invitations to our Practically Perfect Sale events and our annual Club Members Day
- Two year warranty on all Bachmann Branchline, Graham Farish, Bachmann Narrow Gauge and Thomas & Friends™ products
- Discounted entry to selected model railway shows and exhibitions
- The chance to win Bachmann models, heritage railway and exhibition tickets in our competitions

#### Premium Membership All of the benefits of the Standard Membership, plus -

Our annual club membership wagon in either N, OO or OO9 scale depending on the option you chose

#### Deluxe Membership All of the benefits of the Standard Membership, plus -

A choice of having two wagons across two scales, you can choose between:  $1 \times 00 \times 1 \times 00 \times 100 \times 100$ 

For more information either visit our website at www.bachmann-collectorsclub.co.uk or complete the form overleaf and return it to Bachmann Collectors Club



## Warranty Service Request

Please fill in the form overleaf to submit a Warranty Service Request.

- Ensure the form is filled out in full and a brief explanation of the problem is given.
- · Proof of purchase date (preferably a receipt) is required.
- Send this form with the product direct to the retailer that you purchased the model from.

**Please note:** it is essential that the letter of claim reaches the retailer before the last day of this Guarantee. Late claims will not be considered.

#### DCC Decoders

**Please note:** any locomotive returned to the Service Department for attention should, if possible, have any decoder removed. If sent with a decoder fitted please reset the address to 3, service may be restricted. Bachmann Europe PLC only accept liability to the value of a standard model. This also applies to body modifications/detailing.



## **Bachmann Collectors Club**

Membership Information Request Form

Name:	
Address:	
Town/City:	Postcode:
Email:	
Please return to:	
Bachmann Collect PO Box 7820, Barwell, Leicestershire. LE9 8WZ England	tors Club
	BACHMANN Europe plc Quality Since 1833
14/2 4442 12	
Name:	ty Service Request Form
	Postcode:
Tel. No:	
Email:	
Retailer where purchase	pd:
Description of Problem:	