

Thank you for your choice of the Graham Farish Class 08 diesel locomotive.

Running in

The mechanism of this model requires running in (without a load) for approximately 1 hour in each direction at moderate speed.

Curves

This locomotive is suitable for use on track with curves of first radius (approx. 9 inches / 225 mm) or greater

Body removal

Remove the four screws, two each end of the chassis, as indicated on the diagram.



Take care to remove the conduit wire from the bonnet end lamps from the front step

Lubrication

When required, sparingly lubricate the motor bearings and gear train using plastic compatible light oil. Suitable lubricants are Bachmann E-Z Lube item 99984 or Woodland Scenics 'HobbyLube' Lite Oil item HL654.

Graham Farish N scale models should not be run with a DCC controller unless a DCC decoder has been fitted as damage to the motor may result



Class 08 0-6-0 diesel shunter

Parts

- 1 Motor
- 2 Driving wheels
- 3 Pickups
- 4 Gears
- 5 Loco baseplate

When ordering parts please quote the catalogue number together with the livery of the model (if appropriate) and number of the part required.

Parts are subject to availability. Couplings for the model are available in packets from retailers - item 379-401

The model should be handled carefully as it has many finely detailed parts. It is not suitable for persons under 14 years

Bachmann Europe Plc

Moat Way, Barwell, Leicestershire, LE9 8EY 01455 841756 www.bachmann.co.uk Class 08 rev 2 08/14 F7101-IS001

